

## Fitting instructions for 'Sebring' valance

Drill a ¼ inch clearance hole through the base of each lamp housing and rear valance. This supports the panel in position while you align everything. With panel held in position drill 1/8 inch holes vertically down inside trunk. You can pop rivet or use sheet metal screws to pull panel tight to body panel. Use a small amount of body-seal putty in the joint.

